

Installation & Fitting Instructions

MILENCO

2004 Super Heavy Duty 3004 Hitchlock



Ensure stabiliser red handle is in an upright position and the black handle is in the down position



Place the body of hitchlock over the black handle ensuring it is located into the slot in the inside top corner of the hitchlock



Place the bolt through the hole on the hitchlock body



Push the 2 sections of the locking bolt together



Turn key to lock the mechanism



The hitch is now secure